

An Overview of the City of Falls Church's New Voting System



Welcome eSlate!






The Buttons



Press
ENTER to vote for a selected choice.





Use
NEXT
to go to
the next
page.



Turn the **SELECT** wheel to highlight your choices.



Use the CAST
BALLOT button at
the very end to
cast your ballot.



Press **HELP** to get help.



Special Features





What will happen when you arrive at the polling place?



ACCESS CODE


1234


Date: 05-01-2000
Time: 08:00:00
Place: Town Hall

- When you arrive to vote, you will sign in as always.
- You'll see new voting booths.
- An election official will give you a 4-digit "Access Code."



Enter Your Access Code





- 1. Turn the **SELECT** wheel to highlight the first number of your Access Code.
- 2. Press **ENTER** to choose that number.
- 3. Repeat for all numbers of your Access Code.
- 4. When the last digit in your code has been entered, you will see the first page of your ballot.



Make Ballot Choices

Council Member Abraham Lincoln Alexander Hamilton




- Turn the SELECT wheel until your choice is highlighted in blue.
- 2. Press **ENTER**. The box to the left of your choice will turn red to show your vote.
- 3. The blue highlight bar will move to the next contest title.
- 4. Continue through the ballot until you have voted in all the contests you wish to vote.
- 5. You may use the **PREV** or **NEXT** buttons at any time to move through the ballot.




How to Do a Write-In Candidate

To enter a write-in, just turn the wheel to each letter needed to spell the name of your choice, pressing **ENTER** after each letter. Then turn the wheel to highlight "ACCEPT" and press **ENTER** to return to your ballot.





Review Your Ballot





Press PREV for previous page.

To complete your voting and cast your ballot, press CAST BALLOT.

- ✓ After you have voted on all the pages of the ballot, a Ballot Summary page appears, allowing you to review your selections.
- ✓ To change your vote, turn the SELECT wheel until the contest you want to change is highlighted, then press ENTER. You will return to that contest.
- ✓ You may use the PREV and NEXT buttons to review your ballot.



Cast Your Ballot


Only after you are completely finished voting and reviewing your ballot, press the CAST BALLOT button.





Cast Your Ballot

Your vote has been recorded when you see the waving American Flag.





Ballot Now, the Absentee By-Mail System

- ■Visit www.fallschurchva.gov or the Voter Registration Office in City Hall to obtain an Absentee Ballot
- •Use a **BLUE** or **BLACK** pen to completely fill the Box beside your choice, as shown here.
- •Do not fill in more choices than allowed.
- If you make a mistake, you may correct it by crossing out the incorrect choice with an X and marking your true choice.
- ■You must sign and date the voter's affidavit.
- Make sure you mail your ballot no later than Election Day.

